

# COOLON XBLADE<sup>TM</sup> 480 INDUSTRIAL LED MANUAL EDITION 2.1



## MOUNTING CONFIGURATIONS


#### **Horizontal Plane**

To mount the XBLADE<sup>™</sup> it is recommended to use: 4 x M16 Grade A4 Stainless (316) bolts\* **OR** 4 x M16 grade 8.8 galvanised High Tensile Steel bolts\*




#### Horizontal Plane - Suspended

To mount the XBLADE<sup>™</sup> it is recommended to use: 4 x M16 Grade A4 Stainless (316) bolts\* **OR** 4 x M16 grade 8.8 galvanised High Tensile Steel bolts\*




NOTE: The XBLADE<sup>™</sup>, may be mounted to various surfaces and with fewer than the recommended number of bolts, however, the customer is responsible to identify potential risks associated with the installation and to ensure appropriate measures are taken to maintain safety and proper working order. This may include the use of custom brackets, fall arrest hardware, etc. \*Mounting hardware not supplied by Coolon.

### **Vertical Plane**



**NOTE:** XBLADE 480 can rotate 360°. Please be aware of the power cable's position with respect to the angle of the luminaire, avoid cable damage due to excessive bending. When using the locking / securing screws 1 screw per side will be sufficient however some angles allow for an additional screw if desired.






support@coolon.com.au • aus. 1300 287 533 • intl. +613 8681 3633 • www.coolon.com.au Product must be installed by a suitably qualified person. All documentation is subject to change without notice. Refer to our website for the latest information.


## SIZING AND SPACING

### **Remote Power Supply**




#### **CONNECTION - MAINS**

Open the junction box by rotating the lid counter-clockwise



## 415VAC DELTA




X

Once the product has reached end of life, unit is to be disposed of in accordance to local e-waste laws or regulations. Do not dispose of these products as unsorted municipal waste: take them for recycling. For information on your nearest recycling point, check with your local waste authority.


#### **CONNECTION - RPS**

Remove the junction box lid (4  $\times$  M6 SEMS Captive Screws) and connect wires from power supplies as per the diagram below.

**NOTE:** No Polarity Protection. Observe correct DC polarity between power supply and luminaire. **Cable glands not included.** Size: M25x1.5. Cable gland with strain relief is recommended.




### Kit Configuration (230VAC)



230VAC nominal input voltage

PWR-CLN-600-CC2800-381AL-MP230

#### Kit Configuration (415VAC DELTA)



Distance between the power supply and luminaire can be extended up to 100 metres using a min 1.5mm<sup>2</sup>.

NTC: Negative Temperature Coefficient.

